

Instructions: - Square Arch

Tools Required:

- Medium sized flathead screwdriver or round file to file any metal shards.
- Small step if you plan to build the arch standing,

NOTE: Parts may be hard to get together the first time due to the paint coating and occasional metal left in tubes from the manufacturing process.

1. Unpack all parts and layout on the floor in the order shown in the photo below.



2. Attach the middle bar which is a female female connector type to the 2 parts with a tpiece. This will form the top bar of the arch.



3. Attach one male female part to each of the base plates, then another male female part



4. Insert the final female parts onto the uprights



5. Slide the top bar onto the uprights.

NOTE: there are no wing nuts to tighten on the top of the uprights where the tpiece is positioned.

